Single current input, double current/voltage output




Single voltage input, double current/voltage output

B. Pry the metal lock off the rail with screwdriver as arrow shown, pull downward the springs, and rotate the devices.

C. Remove the devices as arrow shows.

- As far as possible to mount it vertically, in order to dissipation the heat of the apparatus.

Vertically installation

### ➔ Light indication

- **PWR**: Power indicator light shows green, it means work normally.
- **ALM**: Input signal state indicator (red), it is off during

### ➔ Attention

- This devices degree of protection is IP 20 and must be protected from undesirable ambient conditions (waterproofing, small foreign objects). It is suitable for installation in the control room or high density field cabinet, DIN 35 mm installation is convenient for installation and displacement.
- The devices were designed for use in pollution degree 2 and overvoltage category III as per IEC/EN 60664- . If used in areas with higher pollution degree, the devices need to be protected accordingly.
- Installation position shall not be affected by strong mechanical vibration; impact and electromagnetic induction from signal terminal and power supply, should conformity with the requirements on electromagnetic interference resistance of products in Class 3 industrial field atmosphere stipulated in IEC 6 000-4; the atmosphere shall be free from gases that are corrosive to metal and plastic components.
- The apparatus must be installed, connected and adjusted by qualified